

Carry out replacement in the following order:

1

Tighten the parking brake lever.

2

Place wedge blocks under the rear wheels.

3



Loosen the wheel mounting bolts.

4

Raise the front of the car and secure on supports.

5



Remove the front wheels.

6



Unscrew the ball joint fastening to the steering
knuckle.

7



Disconnect the lower arm from the steering knuckle.

8



Unscrew the front arm fastener.

9



Unscrew the rear arm fastener.

10.1



Remove the arm.

10.2



11



Install a new arm.

12



Screw the rear arm fastener.

13



Screw the front arm fastener.

14



Connect the lower arm to the steering knuckle.

15

Tighten the ball joint fastener.

16



Install the wheel.

17



Lower the car and working in a cross order, tighten the wheel bolts.

AutoDoc recommends:

Check and adjust wheel alignment if necessary.

We hope that this information
have been useful for you!

Video tutorials

Watch our detailed video guides about your Citroen C3 repair on our youtube channel. Watch video guides.

AutoDoc online

Highest quality transverse arms for your car Citroen C3 are available on AutoDoc. Go to the website.

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

QUALITY AUTO PARTS



CITROEN



TRANSVERSE ARMS



CITROEN C3



TRANSVERSE ARMS FOR CITROEN



TRANSVERSE ARMS FOR CITROEN C3



i Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement works. AutoDoc shall not be liable for any loss, injury, damage of property, acquired in the repair or replacement process due to incorrect usage or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for informative purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

AUTODOC IN SOCIAL MEDIA

